



2012 CAN AM OUTLANDER

Outlander 800–1000 XT with Composite Rack

If you have any comments, suggestions or questions, please send an email to: info@sawgrip.com

THANK YOU for purchasing SawGrip

You will enjoy the advantages of owning the SawGrip chainsaw carrier for your ATV. SawGrip is made to mount on the front rack. Your chainsaw sets horizontal with the rack.

INSTALLATION:

Remove the front cargo rack bolts from the Can Am rack. Place SawGrip mounting plate on top of cargo rack. Cut out in SawGrip plate goes around raised cargo rack stop. Re-install with the new M6x55mm bolts and washers. (Fig. 2) Use existing nut off old bolts.

SET RESISTANCE:

After Saw Grip is bolted to ATV rack and tightened, open bar clamp up enough so chainsaw bar will go between the rubber pads. Tighten bottom lock nuts leaving about 1/8" gap (Fig. 3) then tighten top T - Handle about the same. Pull on saw. If saw moves easily, tighten bottom and top adjusting nuts and T- Handle until saw has enough resistance to slide out with minimal effort. Once the resistance is set correctly, you will be able to put the saw in or out without always adjusting the lower nuts. To lock saw in place, tighten only the top T-Handle until the saw can't be pulled out. It is recommended to remove saw from The SawGrip before transporting your ATV. **Total chainsaw length must not exceed the width of the ATV.**

