



KAWASAKI

360 PRAIRIE TO 650 BRUTE FORCE 4X4i

If you have any comments, suggestions or questions, please send an email to: info@sawgrip.com

THANK YOU for purchasing SawGrip

You will enjoy the advantages of owning the SawGrip chainsaw carrier for your ATV. SawGrip is made to mount on the front rack. Your chainsaw sets horizontal with the rack.

INSTALLATION:

Install SawGrip on front rack using appropriate holes for your specific machine. (Fig. 1) Line up front of Saw Grip flush with front of ATV front tube. (Fig. 2). A 5/16" hole will have to be drilled in the center of rails for the 450 and 660 rack rails. **NO drilling necessary for 550 and 700.** Mount Saw Grip to the rack using the 5/16" bolts, flat washers and lock nuts provided. Tighten. (Fig 3)

SET RESISTANCE:

After Saw Grip is bolted to ATV rack and tightened, open bar clamp up enough so chainsaw bar will go between the rubber pads. Tighten bottom lock nuts leaving about 1/8" gap (Fig. 4) then tighten top T - Handle about the same. Pull on saw. If saw moves easily, tighten bottom and top adjusting nuts and T- Handle until saw has enough resistance to slide out with minimal effort. Once the resistance is set correctly, you will be able to put the saw in or out without always adjusting the lower nuts. To lock saw in place, tighten only the top T-Handle until the saw can't be pulled out. It is recommended to remove saw from The SawGrip before transporting your ATV. **Total chainsaw length must not exceed the width of the ATV.**

